


VSP-RSM



What is VSP

- ❖ Automated tool developed by DoE/Batelle; adapted and used by EPA
- ❖ Generates maps and optimal, defensible sampling designs
- ❖ Supports decision-making in the field
- ❖ Provides automated statistics to balance costs and decision risks
(no need for a statistician)
- ❖ Generates documentation to support decisions



What is VSP

VSP provides statistical solutions to sampling design, world-class mathematical and statistical algorithms, and a user-friendly visual interface, while answering two important questions in sample planning.

- ❖ How many samples are needed?
- ❖ Where should the samples be taken?

Statistician in a box

What is VSP

- ❖ Development principally funded by DOE and EPA
- ❖ Generates documentation that supports selection of the right type, quantity, and quality of data required for confident decisions.
- ❖ Non-proprietary; available for free download

VSP-RSM

- ❖ RSEPA will assess potential migration of munitions constituents from operational ranges to off-range areas
- ❖ VSP-RSM supports development of sampling designs to delineate the boundary of soil contamination at the range
- ❖ Interfaces with Operational Range Site Model (ORSM) and common spreadsheet formats

VSP-RSM

- ❖ Comparability

- VSP-RSM will promote consistency in sampling design
 - Allows for range data to be easily compared and rated.

- ❖ Flexibility

- Promotes Dynamic Work Plans


VSP-RSM

- ❖ Dynamic Work Plan
 - Flexible approaches that determine how subsequent data collection activities should proceed in the field.
 - Use a decision tree to guide project teams
 - ♦ where to sample next
 - ♦ how many samples to collect
 - ♦ when sampling can be stopped.

VSP-RSM

Perimeter Transect Sampling.

- ❖ Determines the required spacing and placement of sampling points along the assumed source area boundary (Transect Lines).
- ❖ Multiple increment sampling is employed (EPA/QA G-5s)
 - Improves the representativeness of samples
 - Manages sampling uncertainty due to inherent site variability.




VSP-RSM


- ❖ Multiple Increment Sampling
 - Is the collection of material from adjacent locations, that are in a single sampling unit, and combining them into one sample
 - ♦ This accounts for the heterogeneity of the munitions constituents in the soil
 - ♦ In VSP-RSM each sampling unit is made up of 5 points and each sampling point has 5 separate increments, resulting in 25 increments for each sample

VSP-RSM


- ❖ For each segment on the boundary where the initial Perimeter Transect Sampling shows munitions constituent concentrations exceeding the relevant screening values, VSP-RSM selects subsequent sample points by triangulating out from that segment.




VSP-RSM Example




VSP-RSM Example




VSP-RSM Example



VSP-RSM Example



VSP-RSM Example



VSP-RSM Example

